

ANNUNCIATOR PANEL



Asenware AW-D116 Addressable Annunciator is used with AW-FP100 Series Intelligent Fire Alarm Control Panel. LCD screen with backlight makes it convenient to know the location of the event more precisely. AW-D116 is provided using a 90 character, back-lit, alphanumeric display.

Information Messages includes for **Alarm, Fault, Supervisory** and **General Conditions** in a clear and descriptive English Language.

LEDs for Fire, Supervisory and Alarm are also provided with ACK push button. From the Silence push button, panel and Remote Notification appliances can be silenced.

AW-D116 is fully complied with the requirement of EN54-2 and EN 54-4.

FEATURES

- Three Lines of 40 Character each LCD
- LED Indication for Alarm, Fault and Supervisory
- Push Buttons to acknowledge the silence
- Lamp Test from Key Switch
- IP 30 Cabinet

SILENCE AND ACKNOWLEDGE

From Addressable Annunciator Notification Devices can be silenced and Acknowledged to main control panel

ADDRESSABLE ANNUNCIATOR BOARD

Asenware AW-D117 Addressable annunciator board is a 24 Zone Board, which can be configured at the site as per the Fire Alarm System Layout drawing. It includes keyboard, Power LED and buzzer. AW-D118 is extensions 24 zone board. Both can be used with AW-FP100 Series Addressable Fire Alarm Control Panel. One AW-D117 can be connected with 4 pieces of AW-D118 for maximum 120 zones.

Order Information

Model Number	Description
AW-D116	Addressable Annunciator Panel
AW-D117	24 Zones Addressable Annunciator Board
AW-D118	24 Zones Addressable Annunciator Board Extension

